ARB 4X4 ACCESSORIES



- 1. Position bag on the spare rear tyre and hold bag in position
- 2. Prepare main straps on back of tyre making sure they cross over underneath tyre mount (see image)
- 3. Buckle main straps loosely
- 4. Prepare anti-slouch strap by unbuckling and feeding under spare wheel mount, and return to the buckle at the top of the bag
- 5. Bag must be positioned so top lid is in line with top of tyre and position looks level
- 6. Firmly tension anti-slouch strap
- 7. Firmly tension both diagonal main straps
- Once in correct position any excess strap to be re-fed into slide where possible to remove excess length
- 9. Attach security strap to good locking positon and secure with padlock or other lock



STRAP DIAGRAM

ANTI-SLOUCH STRAP

MAIN STRAPS